


Dreirad • triciclo • tricycle

Alter/age
2½ → 4



rolly toys Kundendienst Deutschland:

Tel: +49 (0) 95 68 / 856 - 142

Fax: +49 (0) 95 68 / 856 - 183

e-mail: service@rollytoys.de

2011/07

150.000.800.00

900 015 001 80

096 015 001 80

096 000 027 **

096 000 015 **

064 000 007 **

052 676 007 80

114 000 676 **

max. 1,5 bar

117 107 001 80

096 000 033 **

041 000 058 **

065 000 110 **

CE

BRAKE

1a

2x M6 M6 x 35

1b

1x Ø 32 065 010 002 80

2a

1x Ø 25

2b

1x Ø 25

2d

1x M8 M8 x 40 900 006 881 00

2c

1x Ø 25

2e

1x

3a

2x M6 M6 x 16







3b

1x 052 676 004 80

4

2x M5 Ø 5mm M5 x 35

→ **		
+10	+26	+47
+12	+30	+51
+13	+37	+54
+20	+38	+60
+22	+40	+70
+23	+41	+75
+25	+44	+80




Rolly Toys Italiana SRL
Via Colonna n. 9
I-31025 · S. Lucia di Piave (TV) · Italia
Tel: +39 / 438 / 4466
Fax: +39 / 438 / 27372
www.rollytoys.com
e-mail: info@rollytoys.it

Zuschaltbarer Freilauf / rechts

traino inseribile / a destra
freewheel option / right
roue-libre intégrée / à droite



=




+




Lenkarretierung


blocco di direzione
steering lock
verouillage de direction



+



=



+



Radwechsel

sostituzione ruota • wheel changing • changement de roue

